

Plow Control Kit

KZ Valve



Power Cable



Feed Line



Feed Line: Connect to Brass valve from the manifold
*Make as short as possible



Magnet

Place magnet near cylinder at the end of the stroke



Y-Cable

Plugged into Harness #1 to turn on power and power alternating valve



MIRUSSO ENTERPRISES INC